


How to Adjust the "Float Fail-Safe" Time Duration

Step 1

Unscrew back panel off of controller
(4) total screws



Adjusting Dial is located towards the top in "Blue Color"



Step 2

Use a Phillips screwdriver and turn the dial COUNTER CLOCKWISE until it locks.
This setting will give a operation mode time of approximately 14 minutes or until correct water level is reached.

